

Instructions (31285)

THIS UNIT FITS ONLY:

300CD	81 - 85	300D	81 - 85	300TD	81 - 85
-------	---------	------	---------	-------	---------

Prior to installation of the Control Unit:

- 1- Inspect and clean **fuse contacts** in the fuse box.
- 2- Verify that the **Fuse Amperage is rated as suggested by original manufacturer** to avoid overload and burning of control unit circuit board.
- 3- Check **Auxiliary Pump**, and if needed replace it **prior to installation** of new control unit.

Perform steps 1 - 4 prior to installation.

1. Turn off ignition and disconnect (L) Left and (R) Right connectors from climate control unit.
2. (+) L pin 12 → (-) L pin 10. Turn key to run position. Current draw = less than 1.3 amps. **IF NOT, REPLACE AUXILIARY PUMP OR WARRANTY IS VOID.**
3. (+) R pin 4 → (-) R pin 3. Turn key to run position. Current draw = less than 1.0 amps. **IF NOT, REPLACE MONOVALVE.**
4. (+) R pin 6 → (-) R pin 3 = greater than 35 ohms, **IF NOT, STOP & REPLACE A.C. COMPRESSOR RELAY.**

ProgRama needs your experience and inputs to make a better product. Call or email tech support today 8:30 am to 5:00 pm EST, with your idea, question or problem.

1 800 668-8843

THREE YEAR WARRANTY

1- Call your Wholesale Distributor for a replacement part.

2- If you have difficulties to obtain a replacement, call ProgRama, Inc. We offer up to 48 hrs. turn-around time for bench testing service.

Visit our web site www.programainc.com and become familiar with our products and services.

Warning ! Return Core In ProgRama Box for Proper Core-Deposit Refund

GENERAL TROUBLESHOOTING NOTES

ORIGINAL UNIT PROBLEM

Symptoms	Test/Suspect Problems	Solution
No power, no fan, no flaps.	Check Fuse.	Replace Fuse.
	(+) L pin 12 → (-) L pin 10. Turn key to run position. Current draw = less than 1.3 amps.	Replace Auxiliary pump and Climate Control Unit.
Heat stays on.	(+) R pin 4 → (-) R pin 3 Turn key to run position. Current draw less = less than 1.0 amps.	Replace Monovalve and Climate Control Unit.
No A.C. compressor.	Check A.C. Compressor Fuse.	Replace Fuse.
	(+) R pin 6 → (-) R pin 3 = less than 35 ohms	Replace A.C. Compressor Relay.
	(+) R pin 6 → (-) R pin 3 = greater than 55 ohms	Check ETR switch.
		Check low refrigerant pressure switch / low refrigerant pressure.
	Check A.C Compressor Relay.	

NEW UNIT PROBLEMS

Symptom	Test/Suspect Problem	Solution
Constant heat with no fresh, nozzle, or recirc flap control.	Temperature Control Unit.	Replace Temperature Control Unit.
No automatic fan speed control.	Temperature Control Unit.	Replace Temperature Control Unit.
No fan or fan speed will not change.	Check fuse.	Replace fuse.
	Check fan.	Replace fan.
		Replace Blower Control Unit.

THANK YOU for buying a quality part from ProgRama, Inc of Boca Raton, Florida !