

FOR G19E

# 643 CONTROLLER.

YAMAHA

- ① Main switch
- ② Tow/storage switch
- ③ Accelerator stop switch
- ④ Buzzer
- ⑤ Directional switch
- ⑥ DC motor
- ⑦ Controller
- ⑧ Throttle sensor
- ⑨ Relay
- ⑩ Receptacle
- ⑪ Fuse (3A)
- ⑫ Batteries (6 x 8V)

**COLOR CODE**

B	.....	Black
L	.....	Blue
G	.....	Green
Y	.....	Yellow
R	.....	Red
P	.....	Pink
Br	.....	Brown
W	.....	White
B/R	.....	Black/Red
Y/B	.....	Yellow/Black
R/Y	.....	Red/Yellow
R/W	.....	Red/White

Y-671

